

Adjust local time on EFKON EFAS digital tachographs

Best practice with this tachograph is to leave UTC set to + 00:00h and switch Summertime to AUTO in the Settings/Clock/Summertime menu. Doing this ensures no further user intervention is ever required during daylight savings.

See below instructions for manual setting of UTC offset where summertime is switched off: -

1. From the primary default screen press OK.



2. The first menu you will see is 'Printout', press the right arrow (▶) until 'Settings' is displayed.



3. Press OK to enter the Settings menu; the first option in this menu is 'Display'.



4. Press the right arrow (▶) twice until 'Clock' is displayed.



Time Instruments Ltd
Tel: 01908 449200
Mail: sales@timtach.com

5. Press OK to enter the Clock menu; the first option in this menu is 'Time adjustment'.



6. Press the right arrow (▶) once until 'Time zone' is displayed.



7. Press OK to enter the Time zone adjustment screen.



8. Use the left (◀) or right (▶) arrows to adjust the time in half hour increments until the correct UTC offset is displayed. **BST = UTC + 1 hour / GMT = UTC**



Time Instruments Ltd
Tel: 01908 449200
Mail: sales@timtach.com

9. Press OK to store the new time offset.



10. Press back button 3 times to return the tachograph to the primary default screen.

